

LED Sauna / Steam Room Light – Installation Manual



Product Description

Low-voltage recessed LED light for sauna or steam room use. Operates on 12 V DC via an external driver.

Safety Instructions

- Disconnect mains power before installation.
- Use only the supplied 12 V LED driver.
- Do not install the driver inside the sauna or steam room.
- Installation must be carried out by a qualified electrician.

Installation Steps

1. Drill a mounting hole (Ø 18–22 mm, depending on model).
2. Feed the light cable through the opening.
3. Compress the spring clips and insert the light into the hole.
4. Connect the light to the 12 V DC output of the driver.
5. Connect the driver to 230 V AC (L / N) via a switch.
6. Place the driver in a dry, ventilated area outside the sauna.

Final Check

- Switch on power and verify correct operation.
- Ensure the light is firmly fixed and does not overheat.